



FS 01-01
FLAP CUTTING

Product Description

The FS 01-01 is made for cutting a flap in medical catheter tube. The tube is manual inserted into the sliding tube jig, and the jig and tube are then pulled back. The flap is cut during the pullback process. The FS 01-01 assures that cutting depth and length is kept constant.

Production capacity:

The production capacity is dependent on the CH size of the tube and the experience of the operator.

Tube specifications:

Tube Diameter:	CH/Fr 3-42 (A tube jig is needed for each tube diameter).
Tube Material:	Most thermoplastics.
Tube Length:	Infinite.
Tube Shape:	Nelaton, Tieman, Coude, round open/closed.

Environment:

It is recommended to operate the machine in a clean environment.